




Installation Instructions

FLEX Integra 16 Protected Source Output Module


(Cat. No. 1793-OB16P and -OB16PS)



Module Installation


This module mounts on a DIN rail. It connects to an adapter or another FLEX I/O or Integra module. Note: If using this module with FLEX I/O modules, do not mount between FLEX I/O modules. Mount Integra modules to the right of the FLEX I/O modules. To mount this module:

1. Remove the cover plug (if used) in the male connector of the unit to which you are connecting this module.
2. Position the module on the 35 x 7.5mm DIN rail **A** (A-B pt. no. 199-DR1).
3. Rotate the module onto the DIN rail with the top of the rail hooked under the lip on the rear of the module.




30869-M

4. Press down to lock the module on the DIN rail.




If the module does not lock in place, use a screwdriver of similar device to move the locking tab down, press the module flush with the DIN rail and release the locking tab to lock the module in place.

5. Firmly push the module into the adjacent module/terminal base until the units lock together.



6. Repeat the above steps to install the next module.
7. To remove an Integra module, you must work from the right side and remove one module at a time. To disengage a module from its neighbor, place a common flat-bladed screwdriver between the 2 modules and turn 1/4 turn to separate the modules.



8. Then slide the module away from its left neighbor, and release the locking lever to remove the module from the DIN rail.



ATTENTION: Do not remove this module under power. Removing this module under power will break the electrical backplane (flexbus) connections. This can cause personal injury or property damage by:

- sending an erroneous signal to your system's field devices causing unintended machine motion
- causing an explosion in a hazardous environment
- breaking communication to modules beyond this module

European Union Directive Compliance

If this product has the CE mark it is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

EMC Directive

This product is tested to meet Council Directive 89/336/EEC Electromagnetic Compatibility (EMC) and the following standards, in whole or in part, documented in a technical construction file:

- EN 50081-2 EMC - Generic Emission Standard, Part 2 - Industrial Environment
- EN 50082-2 EMC - Generic Immunity Standard, Part 2 - Industrial Environment

This product is intended for use in an industrial environment.

Low Voltage Directive

This product is tested to meet Council Directive 73/23/EEC Low Voltage, by applying the safety requirements of EN 61131-2 Programmable Controllers, Part 2 - Equipment Requirements and Tests.

For specific information required by EN 61131-2, see the appropriate sections in this publication, as well as the following Allen-Bradley publications:


- Industrial Automation Wiring and Grounding Guidelines For Noise Immunity, publication 1770-4.1
- Automation Systems Catalog, publication B111

This equipment is classified as open equipment and must be mounted in an enclosure during operation to provide safety protection.


Wiring

This module is available with 2 styles of terminations: 1793-OB16P - screw-cage and 1793-OB16PS - spring-clamp. Refer to the wiring figure below.

1793-OB16P



1793-OB16PS



Where: COM = common, V = +24V dc power, 0 thru 15 = outputs

1. Connect individual sensor signal output leads to terminals 0 through 15 on row **A** (channels 0 thru 15 respectively).
2. Connect the associated sensor common lead to a **COM** terminal on row **(B)**.
3. Connect +24V dc voltage to **V** terminal on row **B**.
4. Connect 24V dc common to terminal **COM** on row **A**.
5. If daisy-chaining + 24V dc from this module to the next Integra module, connect a jumper from terminal **V** to terminal 8 on the next 8 point Integra module or terminal **V** on the next 16 point Integra module.
6. If daisy-chaining 24V dc common from this module to the next FLEX Integra module, connect a jumper from terminal **COM** on this module to terminal 0 on the next 8 point Integra module, or to terminal **COM** on the next 16 point Integra module.




ATTENTION: Total current draw through the module's (V) voltage terminals is limited to 10A. Separate power connections to the module may be required.

Wiring Connections

| Channel | Output | Common | Channel | Output | Common |
|---------------|--------|---|---------|--------|--|
| 0 | 0 | connect to corresponding terminal on row B | 8 | 8 | connect to corresponding terminal on row B |
| 1 | 1 | | 9 | 9 | |
| 2 | 2 | | 10 | 10 | |
| 3 | 3 | | 11 | 11 | |
| 4 | 4 | | 12 | 12 | |
| 5 | 5 | | 13 | 13 | |
| 6 | 6 | | 14 | 14 | |
| 7 | 7 | | 15 | 15 | |
| +24V dc | | Power terminals V are internally connected together in the module. | | | |
| 24V dc common | | Common terminals COM are internally connected together in the module. | | | |

Indicators



A = Status indicators - 0 through 15 - shows status of individual outputs





B = Insertable label for writing individual input designations

Memory Mapping

| Bit/Word | 15 | 14 | 13 | 12 | 11 | 10 | 09 | 08 | 07 | 06 | 05 | 04 | 03 | 02 | 01 | 00 |
|----------|----------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| Read | Reserved | | | | | | | | | | | | | | | |
| Write | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |

Where: 0 = Output

Important: Input and output wiring must be in accordance with Class I, Division 2 wiring methods and in accordance with the authority having jurisdiction.

| C-UL and UL Hazardous Location Approval | Approbation d'utilisation dans des environnements dangereux par la C-UL and UL |
|---|--|
| <p>C-UL and UL certifies products for general use as well as for use in hazardous locations. Actual C-UL and UL certification is indicated by the product label as shown below, and not by statements in any user documentation.</p> | <p>La C-UL and UL certifie des produits pour une utilisation générale aussi bien que pour une utilisation en environnements dangereux. La certification C-UL and UL en vigueur est indiquée par l'étiquette produit et non par des indications dans la documentation utilisateur.</p> |
| <p>Example of the C-UL and UL certification product label:</p>  | <p>Exemple d'étiquette de certification d'un produit par la C-UL and UL :</p>  |
| <p>To comply with C-UL and UL certification for use in hazardous locations, the following information becomes a part of the product literature for this C-UL and UL-certified industrial control product.</p> <ul style="list-style-type: none"> This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D, or non-hazardous locations only. The products having the appropriate C-UL and UL markings (that is, Class I, Division 2, Groups A, B, C, D) are certified for use in other equipment where the suitability of combination (that is, application or use) is determined by the C-UL and UL or the local inspection office having jurisdiction Peripheral equipment must be suitable for the location in which it is used. | <p>EPour satisfaire à la certification C-UL and UL en environnements dangereux, les informations suivantes font partie intégrante de la documentation des produits de commande industrielle certifiés.</p> <ul style="list-style-type: none"> Cet équipement ne convient qu'à une utilisation dans des environnements de Classe I, Division 2, Groupes A, B, C, D ou non dangereux. Les produits portant le marquage C-UL and UL approprié (c'est-à-dire Classe I, Division 2, Groupes A, B, C, D) sont certifiés pour une utilisation avec d'autres équipements, les combinaisons d'applications et d'utilisation étant déterminées par la C-UL and UL ou le bureau local d'inspection. L'équipement périphérique doit convenir à l'emplacement d'utilisation. |
| <p>Important: Due to the modular nature of a programmable control system, the product with the highest temperature rating determines the overall temperature code rating of a programmable control system in a Class I, Division 2, location. The temperature code rating is marked on the product label as shown.</p> | <p>Important: De par la nature modulaire des systèmes de commande programmables, le produit ayant le code de température le plus élevé détermine le code de température global du système dans un environnement de Classe I, Division 2. Le code de température est indiqué sur l'étiquette produit.</p> |
| <p>Temperature code rating:</p>  | <p>Code de température :</p>  |
| <p>The following warnings apply to products having C-UL and UL certification for use in hazardous locations.</p> | <p>Les avertissements suivants s'appliquent aux produits ayant la certification C-UL and UL pour une utilisation dans des environnements dangereux.</p> |

| | |
|---|---|
| C-UL and UL Hazardous Location Approval | Approbation d'utilisation dans des environnements dangereux par la C-UL and UL |
| <p>WARNING: Explosion Hazard</p> <ul style="list-style-type: none"> • Substitution of components may impair suitability for Class I, Division 2. • Do not replace components unless power has been switched off or the area is known to be non-hazardous. • Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous. • Do not disconnect connectors unless power has been switched off or the area is known to be non-hazardous. Secure any user-supplied connectors that mate to external circuits on this equipment by using screws, sliding latches, threaded connectors, or other means such that any connection can withstand a 15 Newton (3.4 lb.) separating force applied for a minimum of one minute. • Batteries must only be changed in an area known to be non-hazardous. | <p>AVERTISSEMENT : Risque d'explosion</p> <ul style="list-style-type: none"> • La substitution de composants peut rendre ce matériel inadapté à une utilisation en environnement de Classe I, Division 2. • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de remplacer des composants. • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement. • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs fournis par l'utilisateur pour se brancher aux circuits externes de cet appareil à l'aide de vis, loquets coulissants, connecteurs filetés ou autres, de sorte que les connexions résistent à une force de séparation de 15 Newtons (1,5 kg - 3,4 lb.) appliquée pendant au moins une minute. • S'assurer que l'environnement est classé non dangereux avant de changer les piles. |
| C-UL and UL logo is a registered trademark of the Underwriters Laboratories. | Le sigle C-UL and UL est une marque déposée de la Underwriters Laboratories. |

Specifications - 16 Protected Output Module Cat. No. 1793-OB16P and -OB16PS

| | |
|-----------------------|--|
| Module Type | 16 digital output - sourcing, protected 1793-OB16P - screw-cage terminations 1793-OB16PS - spring-clamp terminations |
| Module Location | DIN rail mounting |
| Number of Channels | 16 (1 group of 16, nonisolated) |
| On-state Voltage | 10V dc minimum 24V dc nominal 31.2V dc maximum |
| On-state Current | 1mA minimum per channel 500mA maximum per channel |
| Surge Current | 1.5A for 50ms, repeatable every 2s |
| Off-state Leakage | 0.5mA maximum leakage |
| On-state Voltage Drop | 0.5V dc maximum |
| Isolation Voltage | 100% tested at 850V dc for 1s between user and system. No isolation between individual channels |

Specifications - 16 Protected Output Module Cat. No. 1793-OB16P and -OB16PS

| | | |
|--|---------------|---|
| Delay Time | Off to On | 0.5ms maximum |
| | On to Off | 1.0ms maximum |
| Flexbus Current | | 80mA maximum |
| Power Dissipation | | 5W @ 31.2V dc |
| Thermal Dissipation | | 17 BTU/hr @ 31.2V dc |
| Indicators | | 16 yellow channel status indicators |
| Fusing | | Outputs are electronically protected |
| External dc Power | Voltage | 19.2-31.2V dc (5% ac ripple) |
| | Current | 60mA |
| Dimensions | Inches | 2.72H x 3.7D x 2.17W |
| | (Millimeters) | (69H x 94D x 80W) |
| Environmental Conditions | | |
| Operational Temperature | | 0 to +55°C (32 to +131°F) |
| Storage Temperature | | -40 to +85°C (-40 to +185°F) |
| Relative Humidity | | 5 to 95% noncondensing |
| Shock | Operating | Tested to 30g peak acceleration, 11(±1)ms pulse width |
| | Nonoperating | Tested to 50g peak acceleration, 11(±1)ms pulse width |
| Vibration | | Tested 5g @ 10-500Hz per IEC68-2-6 |
| Conductors | Wire Size | 12 gauge (4mm ²) to 18 gauge (0.75mm ²) stranded wire rated @ 75°C minimum |
| | Category | 3/64 in (1.2mm) maximum insulation 2 ¹ |
| Screw Terminal Torque | | 5-7 lb-in (0.5-0.6Nm) |
| Agency Certification (when product is marked) | | <ul style="list-style-type: none"> • C-UL listed • C-UL Class I, Division 2 Groups A, B, C and D certified • UL listed • CE marked for all applicable directives • C-Tick marked for all applicable acts |

1 Use this category information for planning conductor routing as described in publication 1770-4.1, "Wiring and Grounding Guidelines for Noise Immunity."

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846